904535

Closed Center

This valve can be converted to closed center by installing a closed center plug (item number 904916 , sold separately). Installs into the conversion plug on outlet side of valve.

Power Beyond

It can also be converted into a power beyond valve by installing a power beyond sleeve (item number 904915 , sold separately). Installs into the conversion plug on outlet side of valve. Outlet port of first valve must be plumbed directly to reservoir.

