


CS1105T

Cast Iron Air Compressor
Exploded View



Parts List of CS1105T

No.	Parts Code	Parts Description	Qty
1	CS1105001	Capscrew Hex M16x120	1
2	CS1105002	Lockwasher 16	1
3	CS1105003	Nut Hex M16	1
4	CS1105004	Flywheel	1
5	CS1105005	Capscrew Hex M8x25	6
6	CS1105006	Washer	6
7	CS1105007	Front Cover	1
8	CS1105008	Gasket.Front Cover	1
9	CS1105009	Oil Seal PD40*65*12	1
10	CS1105010	Front Bearing E7508	1
11	CS1105011	Key B10*60	1
12	CS1105012	Crankshaft	1
13	CS1105013	Rear Bearing E7307	1
14	CS1105014	Capscrew Hex M8x25	8
15	CS1105015	Plastic Oil Filling Plug Assy	1
16	CS1105016	Side Cover.Crankcase	1
17	CS1105017	Gasket.Side Cover	1
18	CS1105018	Crankcase	1
19	CS1105019	Straight Thread G3/4 Oil Sight Glass	1
20	CS1105020	Oil Drain Plug	1
21	CS1105021	Gasket.Adapter Plate	1
22	CS1105022	Lockwasher 8	4
23	CS1105023	Blot M8x25	4
24	CS1105024	Inner Hexhead bolt M6x20	4
25	CS1105025	Lockwasher 6	4
26	CS1105026	Rear Cap	1
27	CS1105027	Breather	1
28	CS1105028	Gasket.C.U.Cover	1
29	CS1105029	C.U.Adapter Plate	1
30	CS1105030	Shim Adjustment	3
31	CS1105031	Gasket.Cylinder to Crankcase	1
32	CS1105032	Cylinder	1
33	CS1105033	Gasket Cylinder Head	1
34	CS1105034	Washer 10	6
35	CS1105035	Capscrew Hex M10x30	6
36	CS1105036	Air Filter Assembly	1
37	CS1105037	Cylinder head	1
38	CS1105038	Washer 12	8
39	CS1105039	Capscrew Hex M12x70	8
40	CS1105040	Gasket Aftercooler	1
41	CS1105041	Capscrew SKT HD M8x25	4
42	CS1105042	Elbow Aftercooler	1
43	CS1105043	Piston Pin	1
44	CS1105044	Aftercooler	1
45	CS1105045	Straighter Connector	1
46	CS1105046	Discharge nut	1
47	CS1105047	Gasket Intercooler	2
48	CS1105048	Pipe Plug	4

No.	Parts Code	Parts Description	Qty
49	CS1105049	Intercooler	1
50	CS1105050	Capscrew Hex M8x90	4
51	CS1105051	Copper gasket.valve seat	5
52	CS1105052	Valve Assembly-LP Inlet	2
53	CS1105053	Space.Intake Valve	3
54	CS1105054	Retainer.Valve.Low Pressure	2
55	CS1105055	Gasket.Valve Cover	3
56	CS1105056	Cover.Valve	3
57	CS1105057	Bolt M8x20	3
58	CS1105058	piston ring HP	1
59	CS1105059	Retainer.Valve Discharge	3
60	CS1105060	Spacer Discharge Valve	3
61	CS1105061	Valve Assembly- HP Inlet	1
62	CS1105062	Valve AssemblyHP/LP Discharge	2
63	CS1105063	Piston Ring LP	1
64	CS1105064	Snap ring Internal 19	4
65	CS1105065	connecting rod	2
66	CS1105066	Wrist pin LP	1
67	CS1105067	Piston LP	1
68	CS1105068	Bearing Insert	4
69	CS1105069	oil dipper	2
70	CS1105070	Piston HP	1