


EXAMPLE DS DOUBLE SELECTOR HYDRAULIC CIRCUIT



- Connect ports 'A' and 'E' to your first cylinder
- Connect ports 'B' and 'F' to your second cylinder
- Connect ports 'C' and 'D' to the work ports of your control valve

Double Selector Valve (Item # 9-6132)

EXAMPLE CIRCUIT USING
SELECTOR SPOOL.
PUSH SPOOL IN TO
SELECT CYLINDER 1.
PULL SPOOL OUT TO
SELECT CYLINDER 2.



NOTE: THREAD SEALANT—
USE OF A QUALITY NON-TEFLON THREAD SEALANT
IS RECOMMENDED FOR TAPERED PIPE THREADS.
(USE OF TEFLON TAPE IS NOT RECOMMENDED.)